



HAPPY HANDS™

Prevent the door slamming shut on
your little one's fingers with the
Happy Hands Door Stopper



INSTRUCTIONS


INSTALLATION

With the door opening away from you, assess the height at which you would like the Happy Hand to be positioned.

This should ideally be out of reach of young children.

Remove the 3mm tape covering and position the Happy Hand with the straight edge of the backplate just touching the frame rebate (see Fig. 1).

Press the Happy Hand firmly into place and allow adhesive to set for 24 hours before using it.



DO NOT USE FOR 24 HOURS
(see note below)

ACTIVATION

To activate the Happy Hand, open the door and simply rotate the device 180 degrees so that the fingers are protruding outwards beyond the edge of the door (see Fig. 2).


To close the door, simply rotate the device 180 degrees in the opposite direction.

Important Notes

Ensure the door surface is free from dirt and grease before installing the Happy Hand.

Please allow 24 hours for the adhesive pad to set before using the Happy Hand.

Do not install the device on fire escape doors, as these are intended to remain closed at all times, except in an emergency.



CAUTION: THIS PRODUCT IS ONLY A DETERRENT AND IS NOT A SUBSTITUTE FOR PROPER ADULT SUPERVISION